

TO TURN ON

COOL mode

Press 冷房

HEAT mode

Press 暖房

DRY mode

Press 除湿

PLASMACLUSTER FAN mode

Press

TO TURN OFF

Press 停止

TO CHANGE TEMPERATURE SETTINGS

Press 温度

TO CHANGE FAN SPEED

Press 風量



TO CHANGE VERTICAL AIRFLOW DIRECTION

To swing the louver.

Press 風向



To adjust airflow direction.

During louver Swing,

Press 風向

